

Hammer Maintenance Chart

Item	Frequency	Action
Grease the gibs	Weekly*	Grease with EP2 grease
Grease the sheaves, swivel plates, etc.	Monthly or sooner*	Verify operation and grease with EP2 grease
Fastening hardware	Monthly or sooner*	Verify no loose, broken or missing hardware
Oil kicker safety stop	Monthly or sooner*	Verify operation and apply a few drops of oil
Inspect hydraulic lines	Daily	Verify no damage and no leaks
Wire rope inspection	Daily	Verify no fraying, kinking, stretching, etc.
<p><i>Weekly* - at least weekly, but sooner if easily accessible</i></p> <p><i>Monthly or sooner* – at least monthly, but sooner if system is boomed down for any reason.</i></p> <p>For additional information not found in this pocket manual, please call Bermingham Foundation Solutions at 1-800-668-9432.</p>		



Lead System Pocket Manual

Web Version 1.0

Bermingham Foundation Solutions
 Wellington Street Marine Terminal
 600 Ferguson Ave. N.
 Hamilton, Ontario, Canada
 Ph. 905-528-0425
 Toll-free 800-668-9432
 Fax. 905-528-6187

www.bermingham.com

Assembly

Always ensure the following:

- Workers are competent in lead system assembly, usage and maintenance.
- All rigging and hoisting practices and equipment complies with all applicable laws, regulations and standards.
- All fastening hardware used for assembly is free of defects (stripped threads, etc.) and replaced as necessary. Lead column sections should not be assembled using nylon insert lock nuts.
- Lead column hard stops are properly installed and not damaged.
- All sheave and rollers rotate freely, are greased, and secured with the required keeper plates and cotter pins (especially on higher

mounted components which are more difficult to access once the assembly is upright).

- Wire ropes are free of defects such as frays, kinks, stretch, etc.

Operation

Only operate the lead system for its intended use, and within the safe working parameters determined and provided by Berminghammer. Consult with Berminghammer regarding any alternate system uses and/or modifications. Always operate and maintain the crane per the manufacturer's guidelines, and all applicable laws, regulations and standards.

Maintenance

Grease

EP2 grease is the approved grease for lead systems.

All sheaves, gibs, and swiveling plates must be kept well lubricated to ensure proper function and to limit the potential for damage.

Ensure grease fittings and grease gun are kept clean to prevent grease contamination and/or plugging of grease fittings. Replace fittings as required.

Depending on environmental conditions, grease each gib grease fittings weekly. All other components should be greased monthly or sooner if possible.

Equipment

Refer to the Equipment Pocket Manuals (Hammers, Drills, etc.) to ensure the necessary maintenance and inspections are performed.

Operational Inspections

Fastening Hardware

Due to the extreme vibrations caused by driving and drilling, all lead column and component fastening hardware must be inspected at least monthly to ensure nothing has loosened, broken or worn.

Wire Rope

On a daily basis, wire rope and attachments must be visually inspected for any signs of damage (fraying, kinking, stretching, etc.) and replaced immediately.

Ensure there is no wire rope wearing on any equipment that could result in wire rope or equipment damage (pile line).

Sheaves and Sheave Pins

Grease monthly, or sooner if possible.

Safety Hardware

Ensure that lead column hard stops are still in place, secure and not damaged.

Ensure the kicker safety stop is in place and is not seized, damaged, or has been engaged and been re-installed/replaced. Verify its functionality and lubricate with a few drops of oil (do not use grease).

Hydraulics

Visually inspect all hydraulic lines daily to ensure there is no damage and leaks in any lines and fittings. Replace as necessary.

Post Operation

Upon job completion, ensure that all hardware that is loosened during lead system disassembly is either fastened tightly or plastic wrapped in place to ensure nothing can become loose during transport.